
	_
NOTES:	
MOTES.	

STEP 1

EITHER PANEL S1 OR S2 WILL HAVE 2 ON THE LONG EDGE. INSTALL MENDING PLATES AS SHOWN USING 3/4" SCREWS INTO PREDRILLED LOCATIONS.



STEP 2

LAY PANEL L1 DOWN ON THE FLOOR AS SHOWN.



STEP 3


INSTALL 2 SUPPORT BRACKETS, M1, M2 AS SHOWN USING 1.25" SCREWS INTO PREDRILLED LOCATIONS.

STEP 4

INSTALL MENDING PLATES ON MAIN BAR TOP (R) USINGS 3/4" SCREWS INTO PREDRILLED LOCATIONS

STEP 5

JOIN ASSEMBLY TO MAIN BAR AT S1



STEP 6

INSTALL THE PANEL LABELED N1 AS SHOWN USING 3/4" SCREWS INTO PREDRILLED LOCATIONS.

STEP 7

INSTALL THE SIDE EXTENSION'S BAR TOP. JOIN USING MENDING PLATES FROM STEP 4 AND CORNER BRACKETS USING 3/4" INTO PREDRILLED LOCATIONS.

